

# Signholder instructions

To insert the Signholder into the ground, place your foot as per the diagram and push down



To insert the Signholder into the weighted stand, line up the prongs and use your foot as per the diagram to push down

-----  
To remove the Signholder from the ground, place hand as per diagram and just lift out



To remove the Signholder from the weighted stand, place foot on base and lift the Signholder out